



1 T.ali Intelligent power supply and battery charger

2 Main power supply 220 / 24 V dc - ac

3 External battery

4 Standard intercom

5 Cabin control panel with Alarm push button, Alarms sent and Alarm Received signaling and preset for speakerphone.

6 TSA2 System

7 Intercom

8 TSA2 connectors

NOTE:  
Alarm input can be set N/O or N/C.  
Sent and Received alarms are relay contacts.

CONNECTIVITY: UNICO TSA 2, T.ali

revision: may 2011